

Technical Bulletin



HAMMOND ORGAN COMPANY
DIVISION OF HAMMOND CORPORATION
4200 DIVERSEY | CHICAGO, ILLINOIS 60639

March 5, 1968

TO ALL MAINTENANCE ENGINEERS - CHANGES

NO. MODELS

SUBJECT: SERVICE MANUAL T-100 - T-200

57 T-100
T-200

Attached is a copy of the Service Manual for the recently announced T-100 - T-200 organ.

We suggest that you review this manual thoroughly so as to acquaint yourself with this latest solid state organ.

Perhaps the most revolutionary portion of this instrument is the bus amplifiers. This circuitry in the drawbar area is different than prior Hammond organs.

Several changes have been made since the attached manual was printed, we suggest you mark the schematic to show these.

R-811 will be 220 ohms in certain units.

R-821 will be 39K or 47K. Selection is made during final assembly

R-536 will be 33K.

R-529 will be 120K.

A 47K resistor has been added at the Vibrato-On switch, this is equivalent to adding the same resistor from Pin 4 of board 124.000014 to ground.

f

NOTE: This bulletin is a confidential letter to the Hammond dealer organization and is not for general distribution.